This international standard was developed in accordance with internationally recognized principles on standardization established in the Decision on Principles for the Development of International Standards, Guides and Recommendations issued by the World Trade Organization Technical Barriers to Trade (TBT) Committee.



Standard Practice for Extensometers Used in Rock¹

This standard is issued under the fixed designation D4403; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ε) indicates an editorial change since the last revision or reapproval.

1. Scope*

1.1 This practice covers the description, application, selection, installation, data collecting, and data reduction of the various types of contact type extensometers used in the field of rock mechanics. Laser or other non-contact extensometers are not covered here.

1.2 Limitations of each type of extensioneter system are covered in Section 5.

1.3 The values stated in inch-pound units are to be regarded as the standard. The values given in parentheses are mathematical conversions to SI units that are provided for information only and are not considered standard. Add if appropriate, "Reporting of test results in units other than inch-pound shall not be regarded as nonconformance with this standard.

1.4 All observed and calculated values shall conform to the guidelines for significant digits and rounding established in Practice D6026.

1.4.1 The procedures used to specify how data are collected/ recorded or calculated in this standard are regarded as the industry standard. In addition, they are representative of the significant digits that generally should be retained. The procedures used do not consider material variation, purpose for obtaining the data, special purpose studies, or any considerations for the user's objectives; and it is common practice to increase or reduce significant digits of reported data to be commensurate with these considerations. It is beyond the scope of this standard to consider significant digits used in analysis methods for engineering design.

1.5 The text of this standard references notes and footnotes which provide explanatory material. These notes and footnotes (excluding those in tables and figures) shall not be considered as requirements of the standard.

1.6 This practice offers a set of instructions for performing one or more specific operations. This document cannot replace education or experience and should be used in conjunction with professional judgment. Not all aspects of this guide may be applicable in all circumstances. This ASTM standard is not intended to represent or replace the standard of care by which the adequacy of a given professional service must be judged, nor should this document be applied without consideration of a project's many unique aspects. The word "Standard" in the title of this document means only that the document has been approved through the ASTM consensus process.

1.7 This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety, health, and environmental practices and determine the applicability of regulatory limitations prior to use.

1.8 This international standard was developed in accordance with internationally recognized principles on standardization established in the Decision on Principles for the Development of International Standards, Guides and Recommendations issued by the World Trade Organization Technical Barriers to Trade (TBT) Committee.

2. Referenced Documents

2.1 ASTM Standards:²

- D653 Terminology Relating to Soil, Rock, and Contained Fluids
- D3740 Practice for Minimum Requirements for Agencies Engaged in Testing and/or Inspection of Soil and Rock as Used in Engineering Design and Construction
- D6026 Practice for Using Significant Digits in Geotechnical Data

3. Terminology

3.1 *Definitions*—Terms not defined below may appear in Terminology D653.

4. Significance and Use

4.1 Extensioneters are widely used in the field of engineering and include most devices used to measure displacements, separation, settlements, convergence, and the like.

*A Summary of Changes section appears at the end of this standard

Copyright © ASTM International, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959. United States

This is a preview. Click here to purchase the full publication.

¹ This practice is under the jurisdiction of ASTM Committee D18 on Soil and Rock and is the direct responsibility of Subcommittee D18.23 on Field Instrumentation.

Current edition approved Jan. 1, 2020. Published March 2020. Originally approved in 1984. Last previous edition approved in 2012 as D4403–12. DOI: 10.1520/D4403-20.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

4.2 For tunnel instrumentation, extensioneters are generally used to measure roof and sidewall movements and to locate the tension arch zone surrounding the tunnel opening.

4.3 Extensioneters are also used extensively as safety monitoring devices in tunnels, in underground cavities, on potentially unstable slopes, and in monitoring the performance of rock support systems.

4.4 An extensioneter should be selected on the basis of its intended use, the preciseness of the measurement required, the anticipated range of deformation, and the details accompanying the installation. No single instrument is suitable for all applications.

4.5 In applications for construction in rock, precise measurements will usually allow the identification of significant, possibly dangerous, trends in rock movement; however, precise measurement is much less important than the overall pattern of movement.

4.6 Data collection of extensioneters can be simple or low tech, such as manual readings at the instrument location, or complex or high tech where there are electronic readings taken at the site and either downloaded at the instrument locations or transmitted to a data collection and analysis center.

4.7 It is important to realize the pros and cons and costs between each type of extensometers. In the case of manual readings, not as much data may be collected, important data may be missed and the person taking the readings may be put in harm's way and may not be able to safely continue collecting data just when the data is needed the most or becomes more important. Whereas, with electronic data collection as the system becomes more sophisticated, the data collected can be done more safely, provide important data that might be missed, and may allow for real-time data analyses that are timelier and more accurate.

4.8 When very accurate measurements are dictated by certain excavations, for example, the determination of the tension arch zone around a tunnel opening, extensometers which can be adjusted in the field after installation shall be used. In all cases, the accuracy of extensometers, either determined through calibration, should be given in addition to the sensitivity of the transducers.

Note 1—Notwithstanding the statements on precision and bias contained in this test method, the precision of this test method is dependent on the competence of the personnel performing it and the suitability of the equipment and facilities used. Agencies that meet the criteria of Practice D3740 are generally considered capable of competent and objective testing. Users of these test methods are cautioned that compliance with Practice D3740 does not in itself ensure reliable results. Reliable testing depends on many factors; Practice D3740 provides a means of evaluating some of those factors.

5. Apparatus

5.1 *General*—Experience, safety considerations, costs, and engineering judgment are required to match the proper type of extensioneter systems to the nature of the investigation for a given project.

5.1.1 The required precision of measurements necessary will vary with the application, as well as the capability of the measurement device. Examples of precision requirements are as follows:

5.1.1.1 Precision levels better than 0.0012 in. (0.02 mm) for measurements used to determine rock properties using in-situ rock testing (such as plate-jack tests),

5.1.1.2 Precision levels in the range of 0.001 to 0.01 in. (0.025 to 0.25 mm) for measurements in underground tunnels and general construction in rock,

5.1.1.3 Precision levels in the range of 0.01 to 0.04 in. (0.25 to 1 mm) for larger underground openings or rock slopes, and weak rock or soil conditions,

5.1.1.4 Precision levels in the range of 1% of the expected range of movement for very large excavations, such as open pit mines and large moving landslides.

5.1.2 Greater precision is also required for long-term monitoring applications, where displacements are typically smaller than those that occur during construction.

5.2 Extensometers:

5.2.1 Rod Extensometers-A large variety of rod extensometers are manufactured. They range from simple single-point units to complicated multi-position systems using either a manual, an electronic, or combination of manual and electronic measurement devices.. The single-point extensometer is generally used to detect support system failures. The rod can also serve as a safety warning device in hazardous areas. Generally, the rod extensometer is read with a depth-measuring instrument such as a dial gage or depth micrometer, however, various electrical transducers such as LVDTs (linear variable differential transformers), linear potentiometers, and vibrating wire displacement transducers have been used where remote, threshold or continuous readings are required (as shown in Fig. 1). Another type of readout or transducer is a noncontact removable sonic probe digital readout system, which is interchangeable with the depth micrometer type. Depending on the diameter of the hole, multi-position rod extensometers can have up to eight measuring points. Reduced rod diameters are



FIG. 1 Examples of Rod Extensometer, Single Point (top) with a Manual Readout and (bottom) Electronic Readout

required for multi-position instruments and have reportedly been used effectively to depths of at least 350 ft (107 m). The rod acts as a rigid member and must react in both tension and compression. When used in deep applications, friction caused by drill hole misalignment and rod interference can cause erroneous readings. Rods are usually constructed of some type of stainless steel or fiberglass. To reduce temperature effects, something that is typically an issue or concern, rods can be constructed of invar steel, graphite, or composite carbon fiber.

5.2.2 Bar Extensometers—Bar extensometers are generally used to measure diametric changes in tunnels. Most bar extensometers consist of spring-loaded, telescopic tubes that have fixed adjustment points to cover a range of several feet. The fixed points are generally spaced at 1 to 4-in. (25 to 100mm) increments. A dial gage is used to measure the displacements between the anchor points in the rock (as shown in Fig. 2). If the device is not constructed from invar steel, ambient temperature should be recorded, and the necessary corrections applied to the results. Bar extensometers are primarily used for safety monitoring devices in mines and tunnels.

5.2.3 *Tape Extensometers*—Such devices are designed to be used in much the same manner as bar extensometers; however, tape extensometers allow the user to measure much greater distances, such as found in large tunnels or powerhouse openings. Tape extensometers consist of a steel tape (preferably invar steel), a tensioning device to maintain constant tension, and a readout head. Lengths of tape may be pulled out from the tape spool according to the need. The readout may be a dial gage, a vernier, or another suitable gage. and the



FIG. 2 Bar Extensometer

tensioning mechanism may be a spring-loading device or a dead-weight (as shown in Fig. 3 and Fig. 4). The tape and readout head are fastened, or stretched in tension, between the points to be measured. Accuracies of 0.010 to 0.002 in. (0.25 to 0.05 mm) can be expected, depending on the length of the tape and the ability to tension the tape to the same value on subsequent readings, and provided that temperature corrections are made when necessary.

5.2.4 Joint or Crack Meters—One type of a joint or crack meters consists of an extensometer fixed across an exposed rock surface containing a joint (as demonstrated in Fig. 5), and are used to measure displacements along or across joints. The example shown here shows a dial gage, but it could be an electronic or vibrating wire LVDT type transducer that measures the displacement as well. The joint movements to be measured may be the opening or closing of the joint or slippage along the joint. Rod-type extensometers are generally used as joint or crack meters with both ends fixed on opposite sides of the joint surface trace is measured. Preset limit switches are often mounted on the joint meter to serve as a warning device in problem areas such as slopes and foundations.

5.2.5 Wire Extensometers—Such devices utilize a thin stainless steel wire to connect the reference point and the measuring point of the instrument (as shown in Fig. 6). This allows a greater number of measuring points to be placed in a single drill hole. The wire or wires are tensioned by springs or weights. The wire is extended over a roller shiv and connected to a hanging weight. Wire extensometers tensioned by springs have the advantage of variable spring tension caused by anchor movements. This error must be accounted for when reducing the data. Wire-tensioned extensometers have been used to measure large displacements at drill hole depths up to approximately 500 ft (150 m). The instruments used for deep measurements generally require much heavier wire and greater spring tensions. Although wire extensometers are often used in open drill holes for short-term measurements, in areas of poor ground or unstable holes, it is necessary to run a protective sleeve or tube over the measuring wires between the anchors.

5.3 Anchor Systems:

5.3.1 Groutable Anchors-These were one of the first anchoring systems used to secure wire extensometer measuring points in the drill hole. Groutable anchors are also used for rod type extensometers. Initially PVC (poly(vinyl chloride)) pipes clamped between the anchor points were employed to isolate the measuring wires from the grout column (as shown in Fig. 7), however, this arrangement was unreliable at depths greater than 25 ft (7.5 m) because the hydrostatic head pressure of the grout column or the heat of hydration of the cement in the grout often collapsed the PVC tubing when the rated capacity was exceeded. To counteract this condition, oil-filled PVC tubes were tried. The use of oil enabled this method to be used to depths of over 50 ft (15 m) but is no longer recommended because of environmental issues. This can be avoided if PVC schedule 80 is used or if ABS plastic is used instead of PVC, or the temperature of the grout is controlled using ice or cold water in the grout mix. Oil filed tubes. This alternative system

This is a preview. Click here to purchase the full publication.