

Figure 6.31 - Length of stiff bearing

6.7.5.4 Reduction factor $\chi_{\rm F}$ for resistance

(1) The reduction factor χ_F for resistance should be obtained from:

$$\chi_{\rm F} = \frac{0.5}{\lambda_{\rm F}}$$
 but not more than 1,0 (6.136)

where:

j

$$\lambda_{\rm F} = \sqrt{\frac{l_{\rm y} t_{\rm w} f_{\rm ow}}{F_{\rm cr}}} \tag{6.137}$$

$$F_{\rm cr} = 0.9k_{\rm F}Et_{\rm W}^3 / h_{\rm W}$$
(6.138)

 $l_{\rm v}$ is effective loaded length obtained from 6.7.5.5.

(2) For webs without longitudinal stiffeners the factor $k_{\rm F}$ should be obtained from Figure 6.30

(3) For webs with longitudinal stiffeners $k_{\rm F}$ should be taken as

$$k_{\rm F} = 6 + 2(h_{\rm W}/a)^2 + (5,44b_1/a - 0,21)\sqrt{\gamma_{\rm s}}$$
(6.139)

where:

 b_1 is the depth of the loaded sub-panel taken as the clear distance between the loaded flange and the stiffener

$$\gamma_{\rm s} = 10.9I_{sl} / (h_w t_w^3) \qquad \le 13(a / h_w)^3 + 210(0.3 - b_1 / h_w) \tag{6.140}$$

where I_{sl} is the second moment of area (about z–z axis) of the stiffener closest to the loaded flange including contributing parts of the web according to Figure 6.29. Equation (6.140) is valid for $0.05 \le b_1 / h_w \le 0.3$ and loading according to type (a) in Figure 6.30.

6.7.5.5 Effective loaded length

(1) The effective loaded length l_y should be calculated using the two dimensionless parameters m_1 and m_2 obtained from

$$m_1 = \frac{f_{\text{of}} b_{\text{f}}}{f_{\text{ow}} t_{\text{w}}}$$
(6.141)

$$m_2 = 0.02 \left(\frac{h_W}{t_f}\right)^2$$
 if $\lambda_F > 0.5$ otherwise $m_2 = 0$ (6.142)

where $b_{\rm f}$ is the flange width, see Figure 6.31. For box girders, $b_{\rm f}$ in expression (6.141) is limited to $15t_{\rm f}$ on each side of the web.

(2) For cases (a) and (b) in Figure 6.30, $l_{\rm V}$ should be obtained using:

$$l_y = s_s + 2t_f \left(1 + \sqrt{m_1 + m_2}\right)$$
, but $l_y \le$ distance between adjacent transverse stiffeners (6.143)

(3) For case (c) in Figure 6.30, l_y should be obtained as the smaller of the values obtained from the equations (6.143), (6.144) and (6.145). However, s_s in (6.143) should be taken as zero if the structure that introduces the force does not follow the slope of the girder, see Figure 6.31.

$$l_{y} = l_{e} + t_{f} \sqrt{\frac{m_{1}}{2} + \left(\frac{l_{e}}{t_{f}}\right)^{2} + m_{2}}$$
(6.144)

$$l_{\rm y} = l_{\rm e} + t_{\rm f} \sqrt{m_1 + m_2} \tag{6.145}$$

 A_2 where $\langle A_2$

$$l_e = \frac{k_F E t_W^2}{2 f_{\text{ow}} h_W} \le s_s + c \tag{6.146}$$

6.7.6 Interaction

6.7.6.1 Interaction between shear force, bending moment and axial force

(1) Provided that the flanges can resist the whole of the design value of the bending moment and axial force in the member, the design shear resistance of the web need not be reduced to allow for the moment and axial force in the member, except as given in 6.7.4.2(10).

(2) If $M_{\rm Ed} > M_{\rm f,Rd}$ the following two expressions (corresponding to curve (2) and (3) in Figure 6.32) should be satisfied:

$$\frac{M_{\rm Ed} + M_{\rm f,Rd}}{2M_{\rm pl,Rd}} + \frac{V_{\rm Ed}}{V_{\rm w,Rd}} \left(1 - \frac{M_{\rm f,Rd}}{M_{\rm pl,Rd}}\right) \le 1,00$$
(6.147)

A1 $M_{Ed} \le M_{o,Rd}$ (A1 where:

 $\begin{array}{ll} \textcircled{\begin{subarray}{ll} \label{eq:model} \begin{subarray}{ll} \hline \end{subarray} \\ \hline \end{subarray} \end{subarray} & \hline \begin{subarray}{ll} \hline \end{subarray} \\ \hline \end{subarray} \end{subarray} \\ \hline \end{subarray} \end{subarray} & \hline \begin{subarray}{ll} \hline \end{subarray} \\ \hline \end{subarray} \end{subarray} \end{subarray} \end{subarray} \end{subarray} \end{subarray} \\ \hline \end{subarray} \end{subarray}$

(3) If an axial force $N_{\rm Ed}$ is also applied, then $M_{\rm pl,Rd}$ should be replaced by the reduced plastic moment resistance $M_{\rm N,Rd}$ given by

$$M_{\rm N,Rd} = M_{\rm pl,Rd} \left(1 - \left(\frac{N_{\rm Ed}}{(A_{\rm fl} + A_{\rm f2}) f_o / \gamma_{\rm M1}} \right)^2 \right)$$
(6.148)

where A_{f1} , A_{f2} are the areas of the flanges.



Figure 6.32 - Interaction of shear force resistance and bending moment resistance

6.7.6.2 Interaction between transverse force, bending moment and axial force

(1) If the girder is subjected to a concentrated force acting on the compression flange in conjunction with bending moment and axial force, the resistance should be verified using 6.2.9, 6.7.5.1 and the following interaction expression

$$\underbrace{F_{\text{Ed}}}_{F_{\text{Rd}}} + 0.8 \left(\frac{M_{\text{Ed}}}{M_{\text{o},\text{Rd}}} + \frac{N_{\text{Ed}}}{N_{\text{c},\text{Rd}}} \right) \le 1.4$$

$$(6.149)$$

where:

 $\begin{array}{ll} \hline M_{o,Rd} & \hline \\ N_{c,Rd} & \quad \\ \end{array} \ is the design bending moment resistance according to 6.7.2 (4). \\ is the design axial force resistance, see 6.3.1.1. \end{array}$

(2) If the concentrated force is acting on the tension flange the resistance according to 6.7.5 should be verified and in addition also 6.2.1(5)

6.7.7 Flange induced buckling

(1) To prevent the possibility of the compression flange buckling in the plane of the web, the ratio b_w/t_w of the web should satisfy the following expression

$$\frac{b_{\rm W}}{t_{\rm W}} \le \frac{k E}{f_{\rm of}} \sqrt{\frac{A_{\rm W}}{A_{\rm fc}}}$$
(6.150)

where:

 $A_{\rm W}$ is the cross section area of the web $A_{\rm fc}$ is the cross section area of the compression flange $A_{\rm fc}$ is the 0,2% proof strength of the flange material (A)

The value of the factor k should be taken as follows:

-	plastic rotation utilized	k = 0,3
-	plastic moment resistance utilized	k = 0,4
-	A) plastic moment of resistance utilized	k = 0,55 (A1)

(2) If the girder is curved in elevation, with the compression flange on the concave face, the ratio b_W/t_W for the web should satisfy the following criterion:

$$\frac{b_{\rm w}}{t_{\rm w}} \le \frac{kE}{f_{\rm of}} \sqrt{\frac{A_{\rm w}}{A_{\rm fc}}} \frac{1}{\sqrt{1 + \frac{b_{\rm w}E}{3rf_{\rm of}}}}$$
(6.151)

in which r is the radius of curvature of the compression flange.

(3) If the girder is provided with transverse web stiffeners, the limiting value of b_w/t_w may be increased by the factor $1 + (b_w/a)^2$.

6.7.8 Web stiffeners

6.7.8.1 Rigid end post

(1) The rigid end post (see Figure 6.27) should act as a bearing stiffener resisting the reaction from bearings at the girder support, and as a short beam resisting the longitudinal membrane stresses in the plane of the web.

(2) A rigid end post may comprise of one stiffener at the girder end and one double-sided transverse stiffener that together form the flanges of a short beam of length h_f , see Figure 6.27(b). The strip of web plate between the stiffeners forms the web of the short beam. Alternatively, an end post may be in the form of an inserted section, connected to the end of the web plate.

(3) (3) (A) The double-sided transverse stiffener may act as a bearing stiffener resisting the reaction at the girder support (see 6.2.11).

(4) (4) (4) (4) The stiffener at the girder end should have a cross-sectional area of at least $4h_f t_w^2 / e$ where *e* is the centre to centre distance between the stiffeners and $e > 0.1h_f$, see Figure 6.27(b).

(5) (5) (1 If an end post is the only means of providing resistance against twist at the end of a girder, the second moment of area of the end-post section about the centre-line of the web (I_{ep}) should satisfy:

$$I_{\rm ep} \ge b_{\rm w}^3 t_f R_{\rm Ed} / (250W_{\rm Ed}) \tag{6.152}$$

where:

 $t_{\rm f}$ is the maximum value of flange thickness along the girder

 $R_{\rm Ed}$ is the reaction at the end of the girder under design loading

 $W_{\rm Ed}$ is the total design loading on the adjacent span.

6.7.8.2 Non-rigid end post and bolted connection

(1)A non-rigid end post may be a single double-sided stiffener as shown in Figure 6.27(c). It may act as a bearing stiffener resisting the reaction at the girder support (see 6.2.11).

(2) The shear force resistance for a bolted connection as shown in Figure 6.27(c) may be assumed to be the same as for a girder with a non-rigid end post provided that the distance between bolts is $p < 40t_w$.

6.7.8.3 Intermediate transverse stiffeners

(1) Intermediate stiffeners that act as rigid supports of interior panels of the web should be checked for strength and stiffness.

(2) Other intermediate transverse stiffeners may be considered flexible, their stiffness being considered in the calculation of k_{τ} in 6.7.4.2.

(3) Intermediate transverse stiffeners acting as rigid supports for web panels should have a minimum second moment of area I_{st} :

if
$$a/h_{\rm W} < \sqrt{2}$$
: $I_{\rm st} \ge 1.5h_{\rm W}^3 t_{\rm W}^3 / a^2$ (6.153)

if
$$a/h_{\rm W} \ge \sqrt{2}$$
: $I_{\rm st} \ge 0.75h_{\rm W} t_{\rm W}^3$ (6.154)

The strength of intermediate rigid stiffeners should be checked for an axial force equal to $V_{Ed} - \rho_v b_w t_w f_v / \gamma_{M1}$ where ρ_v is calculated for the web panel between adjacent transverse stiffeners assuming the stiffener under consideration removed. In the case of variable shear forces the check is performed for the shear force at distance $0.5h_w$ from the edge of the panel with the largest shear force.

6.7.8.4 Longitudinal stiffeners

(1) Longitudinal stiffeners may be either rigid or flexible. In both cases their stiffness should be taken into account when determining the relative slenderness λ_w in 6.7.4.2(5).

(2) If the value of λ_w is governed by the sub-panel then the stiffener may be considered as rigid.

(3) The strength should be checked for direct stresses if the stiffeners are taken into account for resisting direct stress.

6.7.8.5 Welds

(1) The web to flange welds may be designed for the nominal shear flow $V_{\rm Ed} / h_w$ if $V_{\rm Ed}$ does not exceed $\rho_v h_w t_w f_0 / (\sqrt{3} \gamma_{\rm M1})$. For larger values the weld between flanges and webs should be designed for the shear flow $\eta t_w f_0 / (\sqrt{3} \gamma_{\rm M1})$ unless the state of stress is investigated in detail.

6.8 Members with corrugated webs

(1) For plate girders with trapezoidal corrugated webs, see Figure 6.33, the bending moment resistance is given in 6.8.1 and the shear force resistance in 6.8.2.

NOTE 1 Cut outs are not included in the rules for corrugated webs.

NOTE 2 For transverse loads the rules in 6.7.7 can be used as a conservative estimate.

6.8.1 Bending moment resistance

(1) The bending moment resistance may be derived from:

$$\underbrace{\mathbb{A}}_{2} M_{y,\text{Rd}} = \min \begin{cases} b_2 t_2 h_{\text{f}} f_{\text{of},\text{r}} / \gamma_{\text{M1}} \\ b_1 t_1 h_{\text{f}} f_{\text{of},\text{r}} / \gamma_{\text{M1}} \\ b_1 t_1 h_{\text{f}} \chi_{\text{LT}} f_{\text{of}} / \gamma_{\text{M1}} \end{cases}$$

$$\underbrace{\text{tension flange}}_{\text{compression flange}}$$

$$\underbrace{\text{(6.155)}}_{\text{compression flange}}$$

where A_2 f_{of} is characteristic value of 0,2 % proof strength of the flange material (A2)

A) where $f_{of,r} = \rho_z f_{of}$ includes (A) includes the reduction due to transverse moments in the flanges

$$\boxed{\mathbb{A}_2} \ \rho_z = 1 - 0, 4 \sqrt{\frac{\sigma_x \left(M_z\right)}{f_{\text{of}} / \gamma_{\text{M}1}}} \ \ (6.156)$$

 $M_{\rm Z}$ is the transverse bending moment in the flange

 $\chi_{\rm LT}$ is the reduction factor for lateral torsional buckling according to 6.3.2.

NOTE The transverse moment M_z may result from the shear flow introduction in the flanges as indicated in Figure 6.33(d).



Figure 6.33 - Corrugated web

6.8.2 Shear force resistance

(1) The shear force resistance V_{Rd} may be taken as

$$V_{\rm Rd} = \rho_{\rm c} t_{\rm W} h_{\rm W} \frac{f_{\rm o}}{\sqrt{3} \cdot \gamma_{\rm M1}} \tag{6.157}$$

where ρ_c is the smallest of the reduction factors for local buckling $\rho_{c,1}$, reduction factor for global buckling $\rho_{c,g}$ and HAZ softening factor $\rho_{o,haz}$:

(2) The reduction factor $\rho_{c,l}$ for local buckling may be calculated from:

$$\rho_{c,l} = \frac{1,15}{0,9 + \lambda_{c,l}} \le 1,0 \tag{6.158}$$

where the relative slenderness $\lambda_{c,l}$ for trapezoidal corrugated webs may be taken as

$$\lambda_{\rm c,l} = 0.35 \frac{a_{\rm max}}{t_{\rm W}} \sqrt{\frac{f_{\rm o}}{E}}$$
(6.159)

with a_{max} as the greatest width of the corrugated web plate panels, a_0, a_1 or a_2 , see Figure 6.33.

(3) The reduction factor $\rho_{c,g}$ for global buckling should be taken as

This is a preview. Click here to purchase the full publication.

116

$$\rho_{\rm c,g} = \frac{1.5}{0.5 + \lambda_{\rm c,g}^2} \le 1.0 \tag{6.160}$$

where the relative slenderness $\lambda_{c,g}$ may be taken as

$$\lambda_{\rm c,g} = \sqrt{\frac{f_{\rm o}}{\sqrt{3}\,\tau_{\rm cr,g}}} \tag{6.161}$$

where the value $\tau_{cr,g}$ may be taken from:

$$\tau_{\rm cr,g} = \frac{32.4}{t_w h_w^2} \sqrt[4]{B_{\rm x} B_{\rm z}^3}$$
(6.162)

where:

$$B_{\rm x} = \frac{2a}{a_0 + a_1 + 2a_2} \frac{Et_w^3}{10,9}$$
EL:

$$B_{\rm Z} = \frac{ET_{\rm X}}{2a}$$

2a is length of corrugation, see Figure 6.33

 a_0, a_1 and a_2 are widths of folded web panels, see Figure 6.33

 I_x is second moment of area of one corrugation of length 2*a*, see Figure 6.33.

NOTE Equation (6.162) applies to plates with hinged edges.

(4) The reduction factor $\rho_{o,haz}$ in HAZ is given in 6.1.6.

7 Serviceability Limit States

7.1 General

(1) P An aluminium (A1 structure shall be designed and constructed such that all relevant serviceability criteria are satisfied.

(2) The basic requirements for serviceability limit states are given in 3.4 of EN 1990.

(3) Any serviceability limit state and the associated loading and analysis model should be specified for a project.

(4) Where plastic global analysis is used for the ultimate limit state, plastic redistribution of forces and moments at the serviceability limit state may occur. If so, the effects should be considered.

NOTE The National Annex may give further guidance.

7.2 Serviceability limit states for buildings

7.2.1 Vertical deflections

(1) With reference to EN 1990 – Annex A1.4 limits for vertical deflections according to Figure A1.1 in EN 1990 should be specified for each project and agreed with the owner of the construction work.

NOTE The National Annex may specify the limits.

7.2.2 Horizontal deflections

(1) With reference to EN 1990 – Annex A1.4 limits for horizontal deflections according to Figure A1.2 in EN 1990 should be specified for each project and agreed with the owner of the construction work.

NOTE The National Annex may specify the limits.

7.2.3 Dynamic effects

(1) With reference to EN 1990 - Annex A1.4.4 the vibrations of structures on which the public can walk should be limited to avoid significant discomfort to users, and limits should be specified for each project and agreed with the owner of the construction work.

NOTE The National Annex may specify limits for vibration of floors.

7.2.4 Calculation of elastic deflection

(1) The calculation of elastic deflection should generally be based on the properties of the gross cross-section of the member. However, for slender sections it may be necessary to take reduced section properties to allow for local buckling (see section 6.7.5). Due allowance of effects of partitioning and other stiffening effects, second order effects and changes in geometry should also be made.

(2) For class 4 sections the following effective second moment of area I_{ser} , constant along the beam may be used

$$I_{\text{ser}} = I_{\text{gr}} - \frac{\sigma_{\text{gr}}}{f_{\text{o}}} (I_{\text{gr}} - I_{\text{eff}})$$
(7.1)

where:

 $I_{\rm gr}$ is the second moment of area of the gross cross-section

 $I_{\rm eff}$ is the second moment of area of the effective cross-section at the ultimate limit state, with allowance for local buckling, see $A_1 > 6.2.5.2$

 $\sigma_{\rm gr}$ is the maximum compressive bending stress at the serviceability limit state, based on the gross cross-section (positive in the formula).

(3) Deflections should be calculated making also due allowance for the rotational stiffness of any semi-rigid joints, and the possible recurrence of local plastic deformation at the serviceability limit state.

8 Design of joints

8.1 Basis of design

8.1.1 Introduction

(1)P All joints shall have a design resistance such that the structure remains effective and is capable of satisfying all the basic design requirements given in 2.

(2) The partial safety factors γ_M for joints should be applied to the characteristic resistance for the various types of joints.

NOTE Numerical values for γ_{M} may be defined in the National Annex. Recommended values are given in Table 8.1

 A_1

Resistance of members and cross-sections	γ_{M1} and γ_{M2} see 6.1.3	
Resistance of bolt connections		
Resistance of rivet connections	γ _{M2} = 1,25	
Resistance of plates in bearing		
Resistance of pin connections	γ _{Mp} = 1,25	
Resistance of welded connections	γ _{Mw} = 1,25	
Slip resistance, see 8.5.9.3		
- for serviceability limit states	$\gamma_{\rm Ms,ser} = 1,1$	
- for ultimate limit states	$\gamma_{\rm Ms,ult} = 1,25$	
Resistance of adhesive bonded connections	$\gamma_{Ma} \geq 3,0$	
Resistance of pins at serviceability limit state	$\gamma_{Mp,ser} = 1,0$	
	(^A 1	

Table 8.1 - Recommended partial factors γ_M for joints

(3) Joints subject to fatigue should also satisfy the rules given in EN 1999-1-3.

8.1.2 Applied forces and moments

(1) The forces and moments applied to joints at the ultimate limit state should be determined by global analysis conforming to 5.

(2) These applied forces and moments should include:

- second order effects;
- the effects of imperfections (see 5.3);
- the effects of connection flexibility

NOTE For the effect of connection flexibility, see Annex L.

8.1.3 Resistance of joints

(1) The resistance of a joint should be determined on the basis of the resistances of the individual fasteners, welds and other components of the joint.